



**External amplifier****To remove**

D367R029

1. Remove the right-hand side panel to reveal the amplifier.
- 2.

Unplug the three connectors.



D367R030

3. Undo the three screws securing the amplifier.
4. Remove the amplifier from the console.

**To fit**

Fit in reverse order.