



F9567 9-3
3A/340

9-3 (9400) / 1999 / 3A Electrical, general
 0340 Ignition system - Trionic (1998 - 2003)

Pos	Part No.	Article	Usage	Qty
1	91 78 955	Ignition discharge module	1998-2000, NLS-USE 55561132	1
1	91 87 980	Ignition cassette	1999, B235R, NLS-USE 55559955	1
2	91 67 016	·Lower section		1
3	91 67 032	·Spring Note: Part of 91 78 955		4
4	79 68 316	·Screw Note: Part of 91 78 955		8
5	91 45 764	Screw Note: Engine --2039899	NLS-USE 30551902	4
5	51 25 885	Screw Note: Engine 2039900--		4
6	32 000 330	Spark plug	1998-1999, B204L, (9112541) NGK BCPR7ES-1, 1	4
6	32 000 330	Spark plug	1999-2000, B204E, (9112541) NGK BCPR7ES-1, 1	4
6	91 88 681	Spark plug Note: Engine --Y086666	B235R, B205L, B205R, NGK PFR7H-10, NLS-USE 9399866	4
7	42 27 203	Crankshaft position sensor	1998-2000, B204	1
7	91 77 221	Crankshaft position sensor	1999-2002, B235R, B205, NLS-USE 55557326	1
8	93 166 804	·Support ring Note: Part of 42 27 203	1998-2000	1
9	91 71 117	·O-ring Note: Part of 42 27 203	1998-2000	1
10	79 71 294	Screw	1998-2000, B204	1
10	80 59 552	Screw	1999-2002, B235R, B205	1
11	91 67 024	Aperture disc	NLS-USE 30548369	1
12	91 45 517	Screw	NLS-USE 55557242	1
13	40 63 459	Protection	1998-2000, B204	1
13	91 81 355	Heat shield	1999-2002, B235R, B205	1
14	40 60 083	Clip	1998-2000, B204	1
14	41 58 762	Clip	1999-2002, B235R, B205	1
		Spark plug kit	B204R, B235R Goto 3A - 1330	X